

P H O T O C H R O M I C L E N S

HANDMADE IN ITALY



EN How to maintain and clean KOO's photochromic lens

The anti-fog photochromic lens requires special care and washing due to its hygroscopic properties and its high-water absorption capabilities.

The following steps are necessary for normal cleaning of the lens: wipe the lens with a dry microfibre cloth; wash the lens, using pure alcohol or running water with the addition of neutral soap; dry immediately with a soft cloth, preferably microfibre or cotton. Absolutely avoid using aggressive cleaning sprays on the inner anti-fog layer.

If any marks remain on the lens, this is due to water absorption and is considered normal. To restore the lens to its normal condition and remove these marks, allow the lens to dry in the open air; wipe the entire inside surface of the lens with plenty of neutral soap (without water) until a light lather is obtained; rinse with running water; dry immediately with a soft cloth or air dryer.

IT Manutenzione e pulizia della lente fotocromatica KOO

Grazie alla sua proprietà igroscopica, ossia l'elevata capacità di assorbimento dell'acqua, la lente fotocromatica con trattamento anti-appannamento necessita di particolari attenzioni per la cura e il lavaggio.

Per la normale pulizia della lente è necessario eseguire i seguenti procedimenti: passare la lente con un panno asciutto in microfibra; lavare la lente, utilizzando alcol puro o acqua corrente con l'aggiunta di sapone neutro; asciugare immediatamente tramite un panno morbido, preferibilmente in microfibra o cotone. Evitare assolutamente l'utilizzo di spray detergenti aggressivi sullo strato interno su cui è presente il trattamento anti-appannamento.

Qualora dovessero permanere eventuali segni sulla lente, essi sono dovuti all'assorbimento dell'acqua e sono da considerarsi normali. Al fine di riportare la lente alle sue normali condizioni ed eliminare tali segni, è necessario lasciare asciugare la lente all'aria aperta; passare tutta la superficie interna della lente con abbondante sapone neutro (senza acqua), fino a ottenere una leggera schiuma; risciacquare con acqua corrente; asciugare immediatamente con un panno morbido o un getto d'aria.

// kooworld.cc



KASK S.P.A. Via Firenze 5, 24060 Chiuduno (BG) - ITALY
© 2022 KASK S.P.A. All rights reserved.
420312 - 03/2022



KOO